



Official Lane Maintenance and Capital Equipment Provider

Select Machine



Pattern Information

Date

Pattern TypeRecreational

Pattern DifficultyLow

Pattern Designer

Pattern Volume (ml)27.93

Surface Information

Surface TypeSynthetic

Surface BrandBrunswick Anvil Lane

Age20+

Pattern Parameters

Pattern Number

Pattern Nameライラックオープン

ModeClean & Oil

Forward SpeedMax Clean

Start Cleaner Spray0

Start Squeegee0

Start Oiling6

Split PatternNo

Supplies Information

Lane CleanerMAX10

Cleaner Mixture Ratio: 1

Cleaner Transition Distance

Cleaner Spray End Distance50

Authority22

Envoy

Lane ConditionerCONNECT2.0

Notes

Zone	1	2	3	4	5	6	7	8
Zone End Distance	12	20	26	32	36	40		
Zone Ratio	L 2.9 : 1	3.8 : 1	3.5 : 1	4.6 : 1	5.4 : 1	### : 1	### : 1	### : 1
	R 2.7 : 1	3.8 : 1	3.5 : 1	4.6 : 1	5.4 : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	13.81	7.53	3.28	2.28	1.03	0.00	0.00	0.00

ZONE	7 Pin Side										Board Number										10 Pin Side																		
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	22	22	24	26	32	40	50	60	70	90	95	95	95	95	95	100	100	100	100	100	100	100	100	97	97	97	95	95	95	92	72	62	52	42	34	28	26	25	25
2	13	13	15	17	19	26	35	45	53	70	86	86	86	86	86	86	86	86	86	86	86	86	86	86	86	86	86	86	70	53	45	35	26	19	17	15	13	13	
3	7	7	8	9	10	18	22	36	43	46	47	47	47	47	47	47	47	47	47	47	47	47	47	47	47	47	47	46	43	36	22	18	10	9	8	7	7		
4	2	2	3	4	5	12	14	20	30	33	35	35	35	35	35	35	35	35	35	35	35	35	35	35	35	35	35	35	33	30	20	14	12	5	4	3	2	2	
5	2	2	2	2	3	7	9	14	17	21	24	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	25	24	21	17	14	9	7	3	2	2	2	2	
6																																							
7																																							
8																																							

